









ASSEMBLY INSTRUCTIONS


Read this instruction carefully. Refer hardware and furniture parts list for guidance. Be sure all parts are complete, before assembling. Place all wooden furniture part on a clean and flat soft surface to prevent scratches. Refer steps provided as assembling guide.

CAUTIONS :


- 1.Do not **FULLY-TIGHTEN** the nuts or nut bolts until all are in place.
- 2.To prevent thread damage.Ensure that nuts or nut bolts are not over-tightened.
- 3.Hardware is to be kept out of reach of children.

| PART LIST | | | HARDWARE LIST | | |
|-----------|---|-------|---------------|--|-------|
| ITEM | DESCRIPTION | QTY | ITEM | DESCRIPTION | QTY |
| A | DRESSER | 1 PC | 1 | JCBC SCREW M6 x 70MM  | 8 PCS |
| B | LEGS | 4 PCS | 2 | SPRING WASHER 1/4"  | 8 PCS |
| | | | 3 | FLAT WASHER 1/4"  | 8 PCS |
| | | | 4 | ALLEN KEY M4 (BALL SHAPE) LONG  | 1 PC |
| 7 | L-BRACKET  | 2 PCS | 5 | WALL SCREW M4 x 18MM  | 1 PC |
| 8 | BELT  | 1 PC | 6 | WALL SCREW M4 x 50MM  | 1 PC |


STEP 1




STEP 2




STEP 3




STEP 4



STEP 5



STEP 6



ASSEMBLY COMPLETED