








# ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all part is complete, before you assemble. Place all wooden furniture part on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.


## CAUTIONS :

1. Do not FULLY-TIGHTEN the nut or nut bolt until all nut or bolt is ready assembled.
2. Do not OVER-TIGHTEN the nut or nut bolt to avoid causing damages to the thread.
3. Keep all hardware part out of reach of children.


| PART LIST |                   |       |
|-----------|-------------------|-------|
| ITEM      | DESCRIPTION       | QTY   |
| A         | CHAIR BACK VENEER | 1 PC  |
| B         | FRONT LEG (L & R) | 2 PCS |
| C         | BACK LEG (L & R)  | 2 PCS |
| D         | FRAME SEAT        | 1 PC  |
| E         | CUSHION SEAT      | 1 PC  |

| HARDWARE LIST |  |        |
|---------------|--|--------|
| ITEM          | DESCRIPTION  | QTY    |
| 1             | JCBC SCREW M6 x 25MM            | 4 PCS  |
| 2             | JCBC SCREW M6 x 70MM            | 8 PCS  |
| 3             | SPRING WASHER 1/4"              | 12 PCS |
| 4             | FLAT WASHER 1/4"                | 8 PCS  |
| 5             | PAN HEAD WOOD SCREW M5 X 32MM   | 6 PCS  |
| 6             | WOOD BUTTON ( DIA:14.5)         | 4 PCS  |
| 7             | M4 ALLEN KEY (BALL SHAPE) LONG  | 1 PC   |


## STEP 1 :




## STEP 2 :



## STEP 3 :



## STEP 4 :



COMPLETED CHAIR ASSEMBLY