








# ASSEMBLY INSTRUCTIONS

Read these instructions carefully. Refer to hardware and furniture parts list for guidance. Be sure all parts are complete, before assembling. Place all wooden furniture parts on a clean and flat soft surface to prevent scratches. Refer to steps provided as assembling guide.


## CAUTIONS :

1. Do not **FULLY-TIGHTEN** the nuts or nut bolts until all are in place.
2. To prevent thread damage. Ensure that nuts or nut bolts are not over-tightened.
3. Hardware is to be kept out of reach of children.


PART LIST		
ITEM	DESCRIPTION	QTY
A	CUSHION SEAT	1 PC
B	SIDE LEG ( L & R )	2 PCS
C	BACK REST CUSHION	1 PC
D	FRAME SEAT	1 PC
E	CENTER SUPPORT	1 PC

HARDWARE LIST		
ITEM	DESCRIPTION	QTY
1	JCBC SCREW M6 x 50MM 	6 PCS
2	JCBC SCREW M6 x 35MM 	3 PCS
3	SPRING WASHER 1/4" 	9 PCS
4	FLAT WASHER 1/4" 	3 PCS
5	PAN HEAD WOOD SCREW M5 X 32MM 	8 PCS
6	WOOD DOWEL DIA 8 x 35MM 	12 PCS
7	M4 ALLEN KEY (BALL SHAPE) LONG 	1 PC


## STEP 1 :




## STEP 2 :




## STEP 3 :



## STEP 4 :



## STEP 5 :



COMPLETED CHAIR ASSEMBLY