







# ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all part is complete, before you assemble. Place all wooden furniture part on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.


## CAUTIONS :

1. Do not FULLY-TIGHTEN the nut or nut bolt until all nut or bolt is ready assembled.
2. Do not OVER-TIGHTEN the nut or nut bolt to avoid causing damages to the thread.
3. Keep all hardware part out of reach of children.


PART LIST		
ITEM	DESCRIPTION	QTY
A	CUSHION SEAT	1 PC
B	LEGS (R & L)	2 PCS
C	BACK REST VENEER	1 PC
D	APRON (FRONT & BACK)	2 PCS

HARDWARE LIST		
ITEM	DESCRIPTION	QTY
1	JCBC SCREW M6 x 50MM 	8 PCS
2	JCBC SCREW M6 x 100MM 	4 PCS
3	SPRING WASHER 1/4" 	12 PCS
4	ALLEN KEY M4 ( BALL SHAPE ) 	1 PC
5	PAN HEAD WOOD SCREW M5 X 32MM 	4 PCS
6	WOOD DOWEL DIA 8 x 35MM 	6 PCS


## STEP 1 :




## STEP 1.1 :




## STEP 2 :



## STEP 3 :



## STEP 4 :



COMPLETED CHAIR ASSEMBLY