








# ASSEMBLY INSTRUCTIONS

Read these instructions carefully. Refer to hardware and furniture parts list for guidance. Be sure all parts are complete, before assembling. Place all wooden furniture parts on a clean and flat soft surface to prevent scratches. Refer to steps provided as assembling guide.


## CAUTIONS :

1. Do not **FULLY-TIGHTEN** the nuts or nut bolts until all are in place.
2. To prevent thread damage. Ensure that nuts or nut bolts are not over-tightened.
3. Hardware is to be kept out of reach of children.


PART LIST		
ITEM	DESCRIPTION	QTY
A	BACK REST	1 PC
B	BACK LEG (SET)	1 PC
C	CUSHION SEAT	1 PC

HARDWARE LIST		
ITEM	DESCRIPTION	QTY
1	JCBC SCREW M6 x 80mm (BLACK) 	4 PCS
2	SPRING WASHER 1/4" (BLACK) 	4 PCS
3	BARREL NUT M6 x 13mm 	4 PCS
4	PAN HEAD WOOD SCREW M5 X 32mm 	6 PCS
5	WOOD DOWEL DIA 8 x 25MM 	2 PCS
6	ALLEN KEY M4 ( BALL SHAPE ) 	1 PC
7	WOOD DOWEL DIA 8 x 35MM 	2 PCS


## STEP 1 :



## STEP 2 :



## STEP 3 :



COMPLETED CHAIR ASSEMBLY