








ASSEMBLY INSTRUCTION



step 4: Adjust the leveler
if the table is uneven.



 A x 4pcs	 B x 1 pc	 C x 20 pc	 D x 20 pc	 E x 1 pc
--	---	--	---	---