

ASSEMBLY INSTRUCTIONS


Read this instruction carefully. Refer hardware and furniture parts list for guidance. Be sure all parts are complete, before assembling. Place all wooden furniture part on a clean and flat soft surface to prevent scratches. Refer steps provided as assembling guide.

CAUTIONS :


1. Do not **FULLY-TIGHTEN** the nuts or nut bolts until all are in place.
2. To prevent thread damage. Ensure that nuts or nut bolts are not over-tighten.
3. Hardware are to be kept out of reach from children.

PART LIST			HARDWARE LIST		
ITEM	DESCRIPTION	QTY	ITEM	DESCRIPTION	QTY
A	HEADBOARD (L & R)	2 PCS	1	JCBB SCREW M8 x 16mm	12 PCS
B	SIDERAIL (L & R)	2 PCS	2	JCBC SCREW M6 x 50mm	9 PCS
C	FOOTBOARD	1 PC	3	SPRING WASHER 1/4 "	9 PCS
D	SLAT WITH HOLE (with Belt)	14 PCS	4	FLAT WASHER 1/4 "	6 PCS
E	CENTER SLAT	1 PC	5	M5 ALLEN KEY (SHORT)	1 PC
F	CENTER SLAT SUPPORT	3 PCS	6	M4 ALLEN KEY (LONG)	1 PC
			7	ADJUSTABLE SCREW	3 PCS
			8	PAN HEAD SCREW M4 x 25mm	6 PCS


STEP 1




STEP 2



STEP 3



STEP 4



ASSEMBLY COMPLETED