

ASSEMBLY INSTRUCTIONS

Read these instructions carefully. Refer to hardware and furniture parts list for guidance. Be sure all parts are complete, before assembling. Place all wooden furniture parts on a clean and flat soft surface to prevent scratches. Refer to steps provided as assembling guide.

CAUTIONS :








1. Do not **FULLY-TIGHTEN** the nuts or nut bolts until all are in place.

2. To prevent thread damage. Ensure that nuts or nut bolts are not over-tightened.


3. Hardware is to be kept out of reach of children.

PART LIST		
ITEM	DESCRIPTION	QTY
A	VENEER BACK	1 PC
B	CHAIR LEG (F & B)	2 PCS
C	RAIL (F & B)	2 PCS
D	CUSHION SEAT	1 PC


8	WOOD DOWEL DIA 8 x 25MM	2 PCS
9	WOOD DOWEL DIA 8 x 35MM	8 PCS

HARDWARE LIST		
ITEM	DESCRIPTION	QTY
1	JCBC SCREW M6 x 30MM (BLK) 	4 PCS
2	SPRING WASHER 1/4" (BLK) 	4 PCS
3	JCBC SCREW M6 x 50MM 	4 PCS
4	SPRING WASHER 1/4" 	4 PCS
5	PAN HEAD WOOD SCREW M5 X 32MM 	6 PCS
6	M4 ALLEN KEY (BALL SHAPE) LONG 	1 PC
7	BASE GLIDE C89(Screw) M6 x 23 	4 PCS


STEP 1 :




STEP 2 :



STEP 3 :



STEP 4 :



COMPLETED CHAIR ASSEMBLY