





ASSEMBLY INSTRUCTIONS


Read this instruction carefully. Refer hardware and furniture parts list for guidance. Be sure all parts are complete, before assembling. Place all wooden furniture part on a clean and flat soft surface to prevent scratches. Refer steps provided as assembling guide.

CAUTIONS :


- 1.Do not **FULLY-TIGHTEN** the nuts or nut bolts until all are in place.
- 2.To prevent thread damage.Ensure that nuts or nut bolts are not over-tighten.
- 3.Hardware are to be kept out of reach from children.

PART LIST			HARDWARE LIST		
ITEM	DESCRIPTION	QTY	ITEM	DESCRIPTION	QTY
A	TV CABINET	1 PC	1	PAN HEAD SCREW M5 x 25MM 	6 PCS
B	METAL LEG SUPPORT	2 PCS	2	PAN HEAD SCREW M5 x 32MM 	12 PCS
C	METAL LEG	2 PCS	3	M4 ALLEN KEY (BALL SHAPE)LONG 	1 PC
D	CENTER METAL LEG	1 PC	4	JCBC SCREW M6 x 10MM(BLK) 	8 PCS


STEP 1




STEP 2



STEP 3



STEP 4



ASSEMBLY COMPLETED