

ASSEMBLY INSTRUCTIONS

4 hold indication

Read these instructions carefully. Refer to hardware and furniture parts list for guidance. Be sure all parts are complete, before assembling. Place all wooden furniture parts on a clean and flat soft surface to prevent scratches. Refer to steps provided as assembling guide.


CAUTIONS :

1. Do not **FULLY-TIGHTEN** the nuts or nut bolts until all are in place.
2. To prevent thread damage. Ensure that nuts or nut bolts are not over-tightened.
3. Hardware is to be kept out of reach of children.

PART LIST		
ITEM	DESCRIPTION	QTY
A	LEGS	2 PCS
B	CORNER BLOCK (F & B)	2 PCS
C	CUSHION SEAT	1 PC


HARDWARE LIST		
ITEM	DESCRIPTION	QTY
1	JCBC SCREW M6 x 60MM 	8 PCS
2	SPRING WASHER 1/4" 	8 PCS
3	PAN HEAD WOOD SCREW M4 X 25mm 	8 PCS
4	ALLEN KEY M4 (BALL SHAPE) 	1 PC
5	ADJUSTABLE SCREW 	4 PCS

STEP 1 :




Remark :
Hole marking always front leg


STEP 2 :



STEP 3 :



STEP 4 :



COMPLETED CHAIR ASSEMBLY