







ASSEMBLY INSTRUCTIONS

Read these instructions carefully. Refer to hardware and furniture parts list for guidance. Be sure all parts are complete, before assembling. Place all wooden furniture parts on a clean and flat soft surface to prevent scratches. Refer to steps provided as assembling guide.


CAUTIONS :

1. Do not **FULLY-TIGHTEN** the nuts or nut bolts until all are in place.
2. To prevent thread damage. Ensure that nuts or nut bolts are not over-tightened.
3. Hardware is to be kept out of reach of children.


PART LIST		
ITEM	DESCRIPTION	QTY
A	SIDE LEG (L & R)	2 PCS
B	APRON	1 PC
C	L-SHAPE CUSHION SEAT	1 PC

HARDWARE LIST		
ITEM	DESCRIPTION	QTY
1	JCBC SCREW M6 x 60mm (BLK) 	4 PCS
2	JCBC SCREW M6 x 60mm 	4 PCS
3	SPRING WASHER 1/4" (BLK) 	4 PCS
4	SPRING WASHER 1/4" 	4 PCS
5	ALLEN KEY M4 (BALL SHAPE) 	1 PC
6	BARREL NUT M6 x 13MM 	4 PCS


STEP 1 :



STEP 2 :



STEP 3 :



COMPLETED CHAIR ASSEMBLY