

ASSEMBLY INSTRUCTIONS


Read this instruction carefully. Refer hardware and furniture parts list for guidance. Be sure all parts are complete, before assembling. Place all wooden furniture part on a clean and flat soft surface to prevent scratches. Refer steps provided as assembling guide.

CAUTIONS :


1. Do not **FULLY-TIGHTEN** the nuts or nut bolts until all are in place.
2. To prevent thread damage. Ensure that nuts or nut bolts are not over-tighten.
3. Hardware are to be kept out of reach from children.

PART LIST			HARDWARE LIST		
ITEM	DESCRIPTION	QTY	ITEM	DESCRIPTION	QTY
A	HEADBOARD	1 PC	1	JCBB SCREW M8 x 16MM	8 PCS
B	SIDERAIL (L & R)	2 PCS	2	JCBC SCREW M6 x 20MM (BLK)	8 PCS
C	FOOTBOARD	1 PC	3	JCBC SCREW M6 x 50MM	3 PCS
D	METAL LEG	2 PCS	4	SPRING WASHER 1/4"	3 PCS
E	SLAT	11 PCS	5	PAN HEAD SCREW M4 x 25MM	28 PCS
F	SLAT WITH HOLE	3 PCS	6	M4 ALLEN KEY (BALL SHAPE) LONG	1 PC
G	CENTER SLAT	1 PC	7	M5 ALLEN KEY	1 PC
H	CENTER SLAT SUPPORT	3 PCS	8	ADJUSTABLE GLIDE C167	3 PCS


STEP 1




STEP 2




STEP 4



STEP 5



STEP 6



COMPLETE ASSEMBLY